



NOTES

1. Outside dimensions are for painted cabinets. Add approximately 0.25 inch for carpeted cabinets.
2. Attachment point locations are approximate. Design attachment plates with slotted holes for adjustability.

WARNING! Hanging loudspeakers is a serious undertaking that should be done only by qualified and experienced personnel. Check with an architect or structural engineer to verify any building attachment points. Renkus-Heinz is not responsible for any non-Renkus-Heinz products or for any misuse of Renkus-Heinz products.

THE MATERIAL CONTAINED HEREIN IS PROPRIETARY TO RENKUS-HEINZ AND SHALL NOT BE REPRODUCED DISCLOSED OR USED FOR ANY OTHER PURPOSE WITHOUT THE WRITTEN APPROVAL OF RENKUS-HEINZ.

PART NUMBER LIST			
REV	DESCRIPTION	DATE	BY

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE:	INTL	DATE	RENKUS-HEINZ, inc. TITLE: SPEAKER ASSY, TRX151T, PNX151T & PN151
DECIMALS .XX± .01 .XXX±.005	DRAWN	P.R.	
ANGLES ±0° 30'	CHECK	9/02	
	DESIGN		
	ENG		
	APPROV		
	APPROV		SIZE
	REF DWG		CODE IDENT
NEXT ASSY.	USED ON	DO NOT SCALE DRAWING	DWG NO.
APPLICATION	DEBURR AND REMOVE SHARP EDGES	SCALE	500-SPKRASxxxxxx
			REV
			A
			WEIGHT
			SHEET 1 OF 1