

IC16R-II Array



IC16R-II Assembly



IC16R-II Install Dimensions



WARNING! Hanging loudspeakers is a serious undertaking that should be done only by qualified and experienced personnel. Check with an architect or structural engineer to verify any building attachment points. Renkus-Heinz is not responsible for any non-Renkus-Heinz products or for any misuse of Renkus-Heinz products.

PART NUMBER LIST

REV	DESCRIPTION	DATE	BY

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES
TOLERANCES ARE:
DECIMALS .XX± .01 .XXX±.005
ANGLES ±0° 30'

	INTL	DATE
DRAWN	JM	10-2011
CHECK		
DESIGN		
ENG		
APPROV		
APPROV		
REF DWG:		
DO NOT SCALE DRAWING		

NEXT ASSY. | USED ON
APPLICATION

THE MATERIAL CONTAINED HEREIN IS PROPRIETARY TO RENKUS-HEINZ AND SHALL NOT BE REPRODUCED DISCLOSED OR USED FOR ANY OTHER PURPOSE WITHOUT THE WRITTEN APPROVAL OF RENKUS-HEINZ.

RENKUS-HEINZ, inc.

TITLE:
IC16R-II ASSEMBLY

SIZE	CODE IDENT	DWG NO.	REV

SCALE | WEIGHT | SHEET 1 OF 1

DEBURR AND REMOVE SHARP EDGES